Maintenance procedures for Road Marking Equipment

To ensure that your road marking unit stays in optimal condition follow the below guides.

AFTER EVERY USE:

- 1. Clean all in-line high pressure filter cartridges
- 2. Clean suction filter at end of suction tube
- 3. Check if there is enough piston lube and add if necessary
- 4. Check engine oil level and top-up if necessary

MONTHLY OPERATOR MAINTENANCE TASKS:

- 1. Check tyre pressure on all wheels and make sure they are even
- 2. Remove and wash out foam insert of engine air filter
- 3. Grease all grease nipples
- 4. Set the correct tension on trigger cables
- 5. Check the level of wear on spraying tips